



MICROCHIP

AN587

Interfacing PICmicro® MCUs to an LCD Module

<i>Author:</i>	Mark Palmer
<i>Code:</i>	Mark Palmer/Scott Fink Microchip Technology Inc.

INTRODUCTION

This application note interfaces a midrange PICmicro device to a Hitachi® LM032L LCD character display module, with a two line by twenty character display. LCD modules are useful for displaying text information from a system. In large volume applications, the use of custom LCD displays becomes economical. The routines provided should be a good starting point for users whose applications implement a custom LCD. This source code should be compatible with the PIC16C5X devices, after modifications for the special function register initialization, but has not been verified on those devices.

OPERATION

The Hitachi LM032L LCD character display module can operate in one of two modes. The first (and default) mode is the 4-bit data interface mode. The second is the 8-bit data interface mode. When operating in 4-bit mode, two transfers per character / command are required. 8-bit mode, though easier to implement (less program memory) requires four additional I/O lines. The use of 8-bit mode is strictly a program memory size vs. I/O trade-off. The three most common data interfaces from the microcontroller are:

1. An 8-bit interface.
2. A 4-bit interface, with data transfers on the high nibble of the port.
3. A 4-bit interface, with data transfers on the low nibble of the port.

The LCD module also has three control signals, Enable (E), Read/Write (R_W), and Register Select (RS). The function of each control signal is shown in Table 1.

TABLE 1: CONTROL SIGNAL FUNCTIONS

Control Signal	Function
E	Causes data/control state to be latched Rising Edge = Latches control state (RS and R_W) Falling Edge = Latches data
RS	Register Select Control 1 = LCD in data mode 0 = LCD in command mode
R_W	Read / Write control 1 = LCD to write data 0 = LCD to read data

A single source file, with conditional assembly is used to generate each of these three options. This requires two flags. The flags and their results are shown in Table 2.

TABLE 2: CONDITIONAL ASSEMBLY FLAGS

Flags		
Four_bit	Data_HI	Result
1	0	4-bit mode. Data transferred on the low nibble of the port.
1	1	4-bit mode. Data transferred on the high nibble of the port.
0	x	8-bit mode.

Figure 1, Figure 2, and Figure 3 show the block diagrams for the three different data interfaces. The LCD_CNTL and LCD_DATA lines are user definable to

their port assignment. This is accomplished with EQUATE statements in the source code. See Appendices B, C, and D.

FIGURE 1: 8-BIT DATA INTERFACE




FIGURE 2: 4-BIT MODE; DATA TRANSFERRED ON THE HIGH NIBBLE OF THE PORT





FIGURE 3: 4-BIT MODE; DATA TRANSFERRED ON THE LOW NIBBLE OF THE PORT



LCD's (drivers) are slow devices when compared to microcontrollers. Care must be taken from having communication occur too quickly. The software will need to control communication speed and timing to ensure the slow LCD and fast microcontroller can stay synchronized. The timing requirements of the LM032L are shown in Appendix A. We recommend that the complete specifications of the LM032L be acquired from Hitachi or a Hitachi distributor. The literature numbers are CE-E613Q and M24T013 for a LM032L display driver.


When the module powers up, the default data transfer mode is 8-bit. The initialization sequence only requires commands that are 4-bit in length. The last initialization

command needs to specify the data transfer width (4-or 8-bit). Then a delay of 4.6 ms must be executed before the LCD module can be initialized. Some of the LCD module commands are:

- 1 or 2 lines of characters
- Display on /off
- Clear display
- Increment / do not increment character address pointer after each character
- Load character address pointer


The initialization flow for the module is shown in Figure 4.

FIGURE 4: INITIALIZATION FLOW FOR LCD MODULE



After initialization, each character address is individually addressable. Figure 5 shows the structure of the command to specify the character address.

FIGURE 5: CHARACTER ADDRESS COMMAND FORMAT



The Hitachi Display Drive (HD44780A) has 80 bytes of RAM. The LM032L modules only use 40 bytes of the available RAM (2 x 20 characters). It is possible to use the remaining RAM locations for storage of other information.

Figure 6 shows the display data positions supported by the display driver as well as the characters actually displayed by the module (the non-shaded addresses).

The program example implemented here uses the character auto increment feature. This automatically increments the character address pointer after each character is written to the display.

CONCLUSION

The Hitachi LM032L character display module is well suited for displaying information. The selection of 4-bit or 8-bit data transfer mode is strictly a program memory size vs. I/O resource trade-off. The supplied code is easily used in any of three common data interfaces. The source is easily modifiable to a designers specific application needs. Other display modules/drivers maybe implemented with the appropriate modifications. Table 3 shows the resource requirements for the three subroutines `SEND_CHAR`, `SEND_COMMAND`, and `BUSY_CHECK` in the various data interface modes.

FIGURE 6: DISPLAY DRIVER (DD) RAM LOCATIONS

digit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	- - -	33	34	35	36	37	38	39	40	Display position
line-1	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F	10	11	12	13	14	- - -	20	21	22	23	24	25	26	27	DD RAM address (Hexadecimal)
line-2	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	- - -	60	61	62	63	64	65	66	67	

Note: Shaded locations are not displayed on the LM032L display module.

TABLE 3: RESOURCE REQUIREMENTS

Mode	Program Memory	Data Memory	Verified On
8-bit	32	3	PICDEM-2 ⁽¹⁾
4-bit, Data transferred on the high nibble of the port.	53	3	PICDEM-2 ⁽¹⁾
4-bit, Data transferred on the high nibble of the port.	53	3	Low-Power Real-Time Clock Board (AN582)

Note 1: Jumper J6 must be removed.

APPENDIX A: LM032L TIMING REQUIREMENTS

TABLE A-1: TIMING CHARACTERISTICS

Parameter #	Symbol	Characteristics	Min.	Typ.	Max.	Unit
1	TCYC	Enable cycle time	1.0	—	—	μs
2	PWEH	Enable pulse width	450	—	—	μs
3	TER, TEF	Enable rise / fall time	—	—	25	μs
4	TAS	RS, R/W set-up time	140	—	—	μs
5	TDDR	Data delay time	—	—	320	μs
6	TDSU	Data setup time	195	—	—	μs
7	TH	Hold time	20	—	—	μs

FIGURE A-1: DATA WRITE INTERFACE TIMING





FIGURE A-2: DATA READ INTERFACE TIMING



Note: Refer to Hitachi documentation for the most current timing specifications.

TABLE A-2: LM032L PIN CONNECTION

Pin No.	Symbol	Level	Function	
1	VSS	—	0V	Ground
2	VDD	—	+5V	Power Supply(+)
3	Vo	—	—	Ground
4	RS	H/L	L: Instruction Code Input H: Data Input	
5	R/W	H/L	H: Data Read (LCD module→MPU) L: Data Write (LCD module←MPU)	
6	E	H,H→L	Enable Signal	
7	DB0	H/L	Data Bus Line Note (1), (2)	
8	DB1	H/L		
9	DB2	H/L		
10	DB3	H/L		
11	DB4	H/L		
12	DB5	H/L		
13	DB6	H/L		
14	DB7	H/L		

In the HD44780, the data can be sent in either two 4-bit operations or one 8-bit operation. This flexibility allows an interface to both 4- and 8-bit MPUs.

- Note 1: When interface data is 4-bits long, data is transferred using only 4 lines of DB7:DB4 (DB3:DB0 are not used). Data transfer between the HD44780 and the MPU completes when 4-bits of data is transferred twice. Data of the higher order 4 bits (contents of DB7:DB4 when interface data is 8-bits long) is transferred first and then lower order 4 bits (contents of DB3:DB0 when interface data is 8-bits long).
- 2: When interface data is 8-bits long, data is transferred using 8 data lines of DB7:DB0.

Please check the Microchip BBS for the latest version of the source code. Microchip's Worldwide Web Address: www.microchip.com; Bulletin Board Support: MCHIPBBS using CompuServe® (CompuServe membership not required).

APPENDIX B: 8-BIT DATA INTERFACE LISTING

MPASM 01.40.01 Intermediate LM032L.ASM 4-7-1997 9:43:02 PAGE 1

LOC	OBJECT	CODE	LINE	SOURCE	TEXT
			VALUE		
000001				LIST P=16C64	
000002				ERRORLEVEL -302	
000003	;				
000004	;			This program interfaces to a Hitachi (LM032L) 2 line by 20 character display	
000005	;			module. The program assembles for either 4-bit or 8-bit data interface, depending	
000006	;			on the value of the 4bit flag. LCD_DATA is the port which supplies the data to	
000007	;			the LM032L, while LCD_CNTL is the port that has the control lines (E, RS, RW).	
000008	;			In 4-bit mode the data is transfer on the high nibble of the port (PORT<7:4>).	
000009	;				
000010	;			Program = LM032L.ASM	
000011	;			Revision Date: 5-10-94	
000012	;			1-22-97 Compatibility with MPASMWIN 1.40	
000013	;				
000014	;				
000015	;			include <16c64.inc>	
000001				LIST	
000002	;			P16C64.INC Standard Header File, Version 1.01 Microchip Technology, Inc.	
00238				LIST	
000016					
000017	ADCON1			EQU 9F	
000018					
000019	FALSE			EQU 0	
000020	TRUE			EQU 1	
000021					
000022	;			include <lm0321.h>	
000069				list	
000023	;				
00000001	Four_bit			EQU TRUE	
00000000				EQU FALSE	
000024	;				
000025	Data_HI				
000026	;				
000027	;				
000028	;			if (Four_bit && !Data_HI)	
000029	;				
000030	LCD_DATA			EQU PORTB	
000031	LCD_DATA_TRIS			EQU TRIISB	

```
00032 ;  
00033 else  
00034 ;  
00035 LCD_DATA EQU PORTD  
00036 LCD_DATA_TRIS EQU TRISD  
00037 ;  
00038 endif  
00039 ;  
00040 LCD_CNTL EQU PORTA  
00041 ;  
00042 ;  
00043 ; LCD Display Commands and Control Signal names.  
00044 ;  
00045 ;  
00046 if ( Four_bit && !Data_HI )  
00047 ;  
00048 E EQU 0 ; LCD Enable control line  
00049 RW EQU 1 ; LCD Read/Write control line  
00050 RS EQU 2 ; LCD Register Select control line  
00051 ;  
00052 else  
00053 ;  
00054 E EQU 3 ; LCD Enable control line  
00055 RW EQU 2 ; LCD Read/Write control line  
00056 RS EQU 1 ; LCD Register Select control line  
00057 ;  
00058 endif  
00059 ;  
00060 ;  
00061 TEMP1 EQU 0x030 ; RESET vector location  
00062 ;  
00063 org RESET GOTO START ;  
00064 RESET GOTO START ;  
00065 ;  
00066 ; This is the Peripheral Interrupt routine. Should NOT get here  
00067 ;  
00068 page ISR_V ; Interrupt vector location  
00069 org ;  
00070 PER_INT_V ;  
00071 ERROR1 BCF STATUS, RP0 ; Bank 0  
00072 BSF PORTC, 0  
00073 BCF PORTC, 0  
00074 GOTO ERROR1  
00075 ;  
00076 ;  
00077 ;  
00078 START ; POWER_ON Reset (Beginning of program)
```

```

0008 0183           STATUS          ; Do initialization (Bank 0)
0009 018B           CLRF           INTCON
000A 018C           CLRF           PIR1
000B 1683           BSF            STATUS, RP0      ; Bank 1
000C 3000           MOVWF          0x00          ; The LCD module does not like to work w/ weak pull-ups
000D 0081           OPTION_REG    PIE1          ; Disable all peripheral interrupts
000E 018C           CLRF           OPTION_REG
000F 1283           BCF            PORTA         ; Bank 0
0010 0185           CLRF           PORTB         ; ALL PORT output should output Low.
0011 0186           CLRF           PORTC
0012 0187           CLRF           PORTD
0013 0188           CLRF           PORTE
0014 0189           CLRF           T1CON, TMR1ON ; Timer 1 is NOT incrementing
0015 1010           BCF            T1CON, TMR1ON
0016 1683           BSF            STATUS, RP0      ; Select Bank 1
0017 0185           CLRF           TRISA         ; RA5 - 0 outputs
0018 30F0           MOVWF          0xFO          ; RB7 - 4 inputs, RB3 - 0 outputs
0019 0086           MOVWF          TRISB         ; RC Port are outputs
001A 0187           CLRF           TRISC         ; RC0 needs to be input for the oscillator to function
001B 1407           BSF            T1OSO        ; RD Port are outputs
001C 0188           CLRF           TRISD         ; RE Port are outputs
001D 0189           CLRF           TRISE        ; Enable TMR1 Interrupt
001E 140C           BSF            TMR1IE       ; Disable PORTB pull-ups
001F 1781           BSF            OPTION_REG, NOT_RBPU ; Select Bank 0
0020 1283           BCF            STATUS, RP0      ; Command for 4-bit interface low nibble
0021 0185           CIRF           LCD_CNTL     ; Command for 4-bit interface high nibble
0022 3002           0x02          ; All PORT output should output Low.

00119 DISPLAY_INIT
00120 if ( Four_bit && !Data_HI )
00121   MOVLW 0x02          ; Command for 4-bit interface low nibble
00122 endif
00123 if ( Four_bit && Data_HI )
00124   MOVLW 0x0020         ; Command for 4-bit interface high nibble
00125

```

```

00126      endif
00127      ;
00128      if ( !Four_bit )
00129          MOVLW 0x038           ; Command for 8-bit interface
00130      endif
00131      ;
00132      MOVF   LCD_DATA      ;
00133          BSF    LCD_CNTL, E   ;
00134          BCF    LCD_CNTL, E   ;
00135      ;

00136      ; This routine takes the calculated times that the delay loop needs to
00137      ; be executed, based on the LCD_INIT_DELAY EQUate that includes the
00138      ; frequency of operation. These uses registers before they are needed to
00139      ; store the time.
00140      ;
00141      LCD_DELAY    MOVLW LCD_INIT_DELAY      ; Use MSD and LSD Registers to Initialize LCD
00142          MOVF   MSD           ; Use MSD
00143          CLRF   LSD           ; LSD
00144      LOOP2        DECFSFZ LSD, F           ; Delay time = MSD * ((3 * 256) + 3) * Tcy
00145          GOTO  LOOP2
00146          DECFSFZ MSD, F           ; 
00147      END_LCD_DELAY
00148          GOTO  LOOP2
00149      ;
00150      ; Command sequence for 2 lines of 5x7 characters
00151      ;
00152      CMD_SEQ
00153      ;
00154      if ( Four_bit )
00155          if ( !Data_HI )
00156              MOVLW 0X02           ; 4-bit low nibble xfer
00157          else
00158              MOVLW 0X020          ; 4-bit high nibble xfer
00159          endif
00160      ;
00161      else
00162          MOVLW 0X038           ; 8-bit mode
00163      endif
00164      ;
00165          MOVF   LCD_DATA      ; This code for both 4-bit and 8-bit modes
00166          BSF    LCD_CNTL, E   ;
00167          BCF    LCD_CNTL, E   ;
00168      ;
00169      if ( Four_bit )
00170          if ( !Data_HI )
00171              MOVLW 0X08           ; This code for only 4-bit mode (2nd xfer)
00172          else

```

```

00173      MOVWF    0x080          ; 4-bit high nibble xfer
00174      endif
00175      MOVWF    LCD_DATA        ;
00176      BSF     LCD_CNTL, E       ;
00177      BCF     LCD_CNTL, E       ;
00178      endif
00179      ; Busy Flag should be valid after this point
00180      ; 00181      ;
00182      MOVLW   DISP_ON         ;
00183      CALL    SEND_CMD         ;
00184      MOVLW   CLR_DISP        ;
00185      CALL    SEND_CMD         ;
00186      MOVLW   ENTRY_INC        ;
00187      CALL    SEND_CMD         ;
00188      MOVLW   DD_RAM_ADDR        ;
00189      CALL    SEND_CMD         ;
00190      ; 00191      page
00192      ; 00193      ;Send a message the hard way
00194      MOVLW   'W'
00195      CALL    SEND_CHAR        ;
00196      MOVLW   'i'
00197      CALL    SEND_CHAR        ;
00198      MOVLW   'c'
00199      CALL    SEND_CHAR        ;
00200      MOVLW   'r'
00201      CALL    SEND_CHAR        ;
00202      MOVLW   'o'
00203      CALL    SEND_CHAR        ;
00204      MOVLW   'c'
00205      CALL    SEND_CHAR        ;
00206      MOVLW   'h'
00207      CALL    SEND_CHAR        ;
00208      MOVLW   'i'
00209      CALL    SEND_CHAR        ;
00210      MOVLW   'p'
00211      CALL    SEND_CHAR        ;
00212      MOVLW   B'11000000'
00213      call    SEND_CMD         ;
00214      ;Address DDRam first character, second line
00215
00216      ;Demonstration of the use of a table to output a message
00217      movlw   0
00218      dispmsg
00219      TEMP1
00220
00221      ;Table address of start of message
00222
00223      ;TEMP1 holds start of message address

```

```

0053 2099          call    Table      ;Check if at end of message (zero
0054 39FF          andlw  OFFh      ;returned at end)
0055 1903          00221         btfsf  STATUS, Z
0056 285B          00222         out    STATUS, Z
0057 2063          00223         goto   out
0058 0830          00224         call   SEND_CHAR
0059 3E01          00225         movf   TEMP1, w
005A 2852          00226         addlw  1
005B 285B          00227         dispmsg
005B 285B          00228         out
005B 285B          00229         loop
005B 285B          00230         goto   loop
005B 285B          00231         ;Stay here forever

005C 300C          00232         ; 
005C 300C          00233         INIT_DISPLAY
005D 2072          00234         MOVLW  DISP_ON
005E 3001          00235         CALL   SEND_CMD
005F 2072          00236         MOVLW  CLR_DISP
0060 3006          00237         CALL   SEND_CMD
0061 2072          00238         MOVLW  ENTRY_INC
0062 0008          00239         CALL   SEND_CMD
0062 0008          00240         RETURN
00241         ;
00242         page
00243         ;
00244         ;***** The LCD Module Subroutines
00245         ;* The LCD Module Subroutines
00246         ;***** This routine splits the character into the upper and lower
00247         ;* nibbles and sends them to the LCD, upper nibble first.
00248         if ( Four_bit )      ; 4-bit Data transfers?
00249         ;
00250         if ( Data_HI )      ; 4-bit transfers on the high nibble of the PORT
00251         ;
00252         ;***** This routine splits the character into the upper and lower
00253         ;* nibbles and sends them to the LCD, upper nibble first.
00254         ;*SendChar - Sends character to LCD
00255         ;*This routine splits the character into the upper and lower
00256         ;*nibbles and sends them to the LCD, upper nibble first.
00257         ;
00258         SEND_CHAR
00259         MOVWF  CHAR      ;Character to be sent is in W
00260         CALL   BUSY_CHECK
00261         MOVF   CHAR, w
00262         ANDLW  0xFF00
00263         MOVWF  LCD_DATA
00264         BCF   LCD_CNTL, RW
00265         BSF   LCD_CNTL, RS
00266         BSF   LCD_CNTL, E

```

```

00267      BCF      LCD_CNTL, E
00268      SWAPF   CHAR, W
00269      ANDLW   0xFF0          ;Get lower nibble
00270      MOVWF   LCD_DATA        ;Send data to LCD
00271      BSF      LCD_CNTL, E    ;toggle E for LCD
00272      BCF      LCD_CNTL, E
00273      RETURN
00274      ;
00275      else
00276      ;
00277      ;*****
00278      ;* SEND_CHAR - Sends character to LCD
00279      ;* This routine splits the character into the upper and lower *
00280      ;* nibbles and sends them to the LCD, upper nibble first. *
00281      ;* The data is transmitted on the PORT<3:0> pins
00282      ;*****
00283      ;
00284      SEND_CHAR
00285      MOVWF   CHAR           ; Character to be sent is in W
00286      CALL    BUSY_CHECK       ; Wait for LCD to be ready
00287      SWAPF   CHAR, W
00288      ANDLW   0x0F           ; Get upper nibble
00289      MOVWF   LCD_DATA        ; Send data to LCD
00290      BCF    LCD_CNTL, RW     ; Set LCD to read
00291      BSF    LCD_CNTL, RS     ; Set LCD to data mode
00292      BSF    LCD_CNTL, E      ; toggle E for LCD
00293      BCF    LCD_CNTL, E
00294      MOVF   CHAR, W
00295      ANDLW   0x0F           ; Get lower nibble
00296      MOVWF   LCD_DATA        ; Send data to LCD
00297      BSF    LCD_CNTL, E      ; toggle E for LCD
00298      BCF    LCD_CNTL, E
00299      RETURN
00300      ;
00301      endif
00302      else
00303      ;
00304      ;*****
00305      ;* SEND_CHAR - Sends character contained in register W to LCD
00306      ;* This routine sends the entire character to the PORT *
00307      ;* The data is transmitted on the PORT<7:0> pins
00308      ;*****
00309      ;
00310      SEND_CHAR
00311      MOVWF   CHAR           ; Character to be sent is in W
00312      CALL    BUSY_CHECK       ; Wait for LCD to be ready
00313      MOVF   CHAR, W

```

```

00314      MOVWF   LCD_DATA          ; Send data to LCD
00315      BCF    LCD_CNTL, RW       ; Set LCD in read mode
00316      BSF    LCD_CNTL, RS       ; Set LCD in data mode
00317      BSF    LCD_CNTL, E        ; toggle E for LCD
00318      BCF    LCD_CNTL, E        ; toggle E for LCD
00319      RETURN

00320      ;
00321      endif
00322      ;
00323      page
00324      ;
00325      ;*****Sends command to LCD*****
00326      * Sends command to LCD
00327      * This routine splits the command into the upper and lower
00328      * nibbles and sends them to the LCD, upper nibble first.
00329      * The data is transmitted on the PORT<3:0> pins
00330      ;*****Sends command to LCD*****
00331      ;
00332      if ( Four_bit )      ; 4-bit Data transfers?
00333      ;
00334      if ( Data_HI )      ; 4-bit transfers on the high nibble of the PORT
00335      ;
00336      ;*****Sends command to LCD*****
00337      * SEND_CMD - Sends command to LCD
00338      * This routine splits the command into the upper and lower
00339      * nibbles and sends them to the LCD, upper nibble first.
00340      ;*****Sends command to LCD*****
00341      ;

00342      SEND_CMD
00343      MOVWF   CHAR             ; Character to be sent is in W
00344      CALL    BUSY_CHECK        ; Wait for LCD to be ready
00345      MOVF    CHAR,w           ;
00346      ANDLW  0xFF             ; Get upper nibble
00347      MOVWF   LCD_DATA         ; Send data to LCD
00348      BCF    LCD_CNTL, RW       ; Set LCD to read
00349      BCF    LCD_CNTL, RS       ; Set LCD to command mode
00350      BSF    LCD_CNTL, E        ; toggle E for LCD
00351      BCF    LCD_CNTL, E        ; toggle E for LCD
00352      SWAPF  CHAR,w           ;
00353      ANDLW  0xFF             ; Get lower nibble
00354      MOVWF   LCD_DATA         ; Send data to LCD
00355      BSF    LCD_CNTL, E        ; toggle E for LCD
00356      BCF    LCD_CNTL, E        ; toggle E for LCD
00357      RETURN

00358      ;
00359      else
00360      ;

```

```

0072 00B6          00361 SEND_CMD      CHAR           ; Character to be sent is in W
0073 2081          00362           CALL  BUSY_CHECK    ; Wait for LCD to be ready
0074 0E36          00363           SWAPF
0075 390F          00364           CHAR, W
0076 0086          00365           ANDLW 0x0F          ; Get upper nibble
0077 1085          00366           MOVWF LCD_DATA     ; Send data to LCD
0078 1105          00367           BCF   LCD_CNTL, RW
0079 1405          00368           BCF   LCD_CNTL, RS ; Set LCD to command mode
007A 1005          00369           BSF   LCD_CNTL, E  ; toggle E for LCD
007B 0836          00370           BCF   LCD_CNTL, E
007C 390F          00371           MOVF  CHAR, W
007D 0086          00372           ANDLW 0x0F          ; Get lower nibble
007E 1405          00373           MOVWF LCD_DATA     ; Send data to LCD
007F 1005          00374           BSF   LCD_CNTL, E  ; toggle E for LCD
0080 0008          00375           BCF   LCD_CNTL, E
                                         RETURN

00376
00377 ;endif
00378 else
00379 endif
00380 ;*****
00381 ;***** SEND_CMD - Sends command contained in register W to LCD
00382 ;* This routine sends the entire character to the PORT
00383 ;* The data is transmitted on the PORT<7:0> pins
00384 ;*****
00385 ;*****
00386
00387 SEND_CMD      00388           MOVWF CHAR           ; Command to be sent is in W
00389           CALL  BUSY_CHECK    ; Wait for LCD to be ready
00390           MOVF  CHAR, W
00391           MOVWF LCD_DATA     ; Send data to LCD
00392           BCF   LCD_CNTL, RW
00393           BCF   LCD_CNTL, RS ; Set LCD in read mode
00394           BSF   LCD_CNTL, E  ; Set LCD in command mode
00395           BCF   LCD_CNTL, E
00396           RETURN
00397 ;endif
00398
00399 ;page
00400 ;if ( Data_HI )
00401 ; 4-bit Data transfers?
00402 ; 4-bit transfers on the high nibble of the PORT
00403 ;
00404 ;if ( Data_HI )
00405 ;
00406 ;***** This routine checks the busy flag, returns when not busy
00407 ;*

```

```

00408 ; * Affects:
00409 ; * TEMP - Returned with busy/address
00410 ; *****
00411 ;
00412 BUSY_CHECK
00413 BSF STATUS, RP0 ; Select Register Bank1
00414 MOVLW 0xFF ; Set Port_D for input
00415 MOVWF LCD_DATA_TRIS
00416 BCF STATUS, RP0 ; Select Register Bank0
00417 BCF LCD_CNTL, RS ; Set LCD for Command mode
00418 BCF LCD_CNTL, RW ; Setup to read busy flag
00419 BSF LCD_CNTL, E ; Set E high
00420 BCF LCD_CNTL, E ; Set E low
00421 MOVF LCD_DATA, W ; Read upper nibble busy flag, DDRam address
00422 ANDLW 0xFF0 ; Mask out lower nibble
00423 MOVWF TEMP ; Toggle E to get lower nibble
00424 BSF LCD_CNTL, E ; Read lower nibble busy flag, DDRam address
00425 BCF LCD_CNTL, E ; Mask out upper nibble
00426 SWAPF LCD_DATA, W ; Combine nibbles
00427 ANDLW 0x0F ; Check busy flag, high = busy
00428 IORWF TEMP ; If busy, check again
00429 BTFSR TEMP, 7
00430 GOTO BUSY_CHECK
00431 BCF LCD_CNTL, RW
00432 BSF STATUS, RP0 ; Select Register Bank1
00433 MOVLW 0x0F
00434 MOVWF LCD_DATA_TRIS ; Set Port_D for output
00435 BCF STATUS, RP0 ; Select Register Bank0
00436 RETURN
00437 ;
00438 else
00439 ;
00440 *****
00441 ; This routine checks the busy flag, returns when not busy
00442 ; * Affects:
00443 ; * TEMP - Returned with busy/address
00444 *****
00445 ;
00446 BUSY_CHECK
00447 BSF STATUS, RP0 ; Bank 1
00448 MOVLW 0xFF ; Set PortB for input
00449 MOVWF LCD_DATA_TRIS
00450 BCF STATUS, RP0 ; Bank 0
00451 BCF LCD_CNTL, RS ; Set LCD for Command mode
00452 BCF LCD_CNTL, RW ; Setup to read busy flag
00453 BCF LCD_CNTL, E ; Set E high
00454 BCF LCD_CNTL, E ; Set E low

```

```

0089 0E06          LCD_DATA, W      ; Read upper nibble busy flag, DDram address
008A 39F0          ANDLW 0xFF       ; Mask out lower nibble
008B 00B5          MOVWF TEMP        ;
008C 1405          BSF   LCD_CNTL, E    ; Toggle E to get lower nibble
008D 1005          BCF   LCD_CNTL, E    ; Read lower nibble busy flag, DDram address
008E 0806          MOVF  LCD_DATA, W    ; Mask out upper nibble
008F 390F          ANDLW 0x0F       ; Combine nibbles
0090 04B5          IORWF TEMP, F     ; Check busy flag, high = busy
0091 1BB5          BTFSR TEMP, 7      ; If busy, check again
0092 2881          GOTO  BUSY_CHECK
0093 1085          BCF   LCD_CNTL, RW
0094 1683          BSF   STATUS, RP0    ; Bank 1
0095 30F0          MOVLW 0xFF        ;
0096 0086          MOVWF LCD_DATA_TRIS ; RB7 - 4 = inputs, RB3 - 0 = output
0097 1283          BCF   STATUS, RP0    ; Bank 0
0098 0008          RETURN          ;

00455           ;*
00456           ;*
00457           ;*
00458           ;*
00459           ;*
00460           ;*
00461           ;*
00462           ;*
00463           ;*
00464           ;*
00465           ;*
00466           ;*
00467           ;*
00468           ;*
00469           ;*
00470           ;*
00471           ;*
00472           endif
00473           else
00474           ;
00475           ;*****
00476           ;* This routine checks the busy flag, returns when not busy   *
00477           ;* Affects:   *
00478           ;*      TEMP - Returned with busy/address   *
00479           ;*****
00480           ;*
00481 BUSY_CHECK
00482           BSF   STATUS, RP0    ; Select Register Bank1
00483           MOVLW 0xFF       ; Set port_D for input
00484           MOVWF LCD_DATA_TRIS
00485           BCF   STATUS, RP0    ; Select Register Bank0
00486           BCF   LCD_CNTL, RS    ; Set LCD for command mode
00487           BSF   LCD_CNTL, RW    ; Setup to read busy flag
00488           BSF   LCD_CNTL, E     ; Set E high
00489           BCF   LCD_CNTL, E     ; Set E low
00490           MOVF  LCD_DATA, W    ; Read busy flag, DDram address
00491           MOVWF TEMP        ;
00492           BTFSR TEMP, 7      ; Check busy flag, high=busy
00493           GOTO  BUSY_CHECK
00494           BCF   LCD_CNTL, RW
00495           BSF   STATUS, RP0    ; Select Register Bank1
00496           MOVLW 0x00        ;
00497           MOVWF LCD_DATA_TRIS ; Set port_D for output
00498           BCF   STATUS, RP0    ; Select Register Bank0
00499           RETURN          ;
00500           ;*
00501           endif

```

```

00502      page
00503      ;
00504      Table
00505      addwf PCL, F
00506      ;Jump to char pointed to in W reg
00507      retlw 'M'
00508      retlw 'i'
00509      retlw 'c'
00510      retlw 'r'
00511      retlw 'o'
00512      retlw 'c'
00513      retlw 'h'
00514      retlw 'i'
00515      retlw 'p'
00516      retlw 'T'
00517      retlw 'e'
00518      retlw 'c'
00519      retlw 'h'
00520      retlw 'n'
00521      retlw 'o'
00522      retlw 'l'
00523      retlw 'o'
00524      retlw 'g'
00525      retlw 'y'
00526      Table_End
00527      retlw 0
00528      ;
00529      if ( (Table & 0xFF) >= (Table_End & 0xFF) )
00530      MSG "Warning - User Defined: Table Table crosses page boundary in computed jump"
00531      endif
00532      ;
00533
00534
00535      end
00536      end
MEMORY USAGE MAP ('X' = Used, ' - ' = Unused)
0000 : X--XXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX
0040 : XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX
0080 : XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX-
-----
```

All other memory blocks unused.

Program Memory Words Used: 172
Program Memory Words Free: 1876

```
Errors   : 0 reported,  
Warnings : 0 reported,  
Messages : 0 suppressed,  
          12 suppressed
```

Please check the Microchip BBS for the latest version of the source code. Microchip's Worldwide Web Address: www.microchip.com; Bulletin Board Support: MCHIPBBS using CompuServe® (CompuServe membership not required).

APPENDIX C: 4-BIT DATA INTERFACE, HIGH NIBBLE LISTING

MPASM 01.40.01 Intermediate LM032L.ASM 4-7-1997 9:50:32 PAGE 1

LOC	OBJECT	CODE	LINE SOURCE TEXT
		VALUE	

```

00001    LIST P=16C64
00002        ERRORLEVEL -302
00003 ;
00004 ; This program interfaces to a Hitachi (LM032L) 2 line by 20 character display
00005 ; module. The program assembles for either 4-bit or 8-bit data interface, depending
00006 ; on the value of the 4bit flag. LCD_DATA is the port which supplies the data to
00007 ; the LM032L, while LCD_CNTL is the port that has the control lines ( E, RS, RW ). .
00008 ; In 4-bit mode the data is transfer on the high nibble of the port ( PORT<7:4> ) .
00009 ;
00010 ; Program = LM032L.ASM
00011 ; Revision Date : 5-10-94
00012 ;                                         1-22-97
00013 ;
00014 ;
00015     include <p16c64.inc>
00001    LIST
00002 ; P16C64.INC Standard Header File, Version 1.01      Microchip Technology, Inc.
00016
00017 ADCON1   EQU  9F
00018
00019 FALSE    EQU  0
00020 TRUE     EQU  1
00021
00022 include <lm032l.h>
00069    list
00023 ;
00024 Four_bit  EQU  FALSE      ; Selects 4- or 8-bit data transfers
00025 Data_HI   EQU  TRUE       ; If 4-bit transfers, Hi or Low nibble of PORT
00026 ;
00027 ;
00028     if ( Four_bit && !Data_HI )
00029 ;
00030 LCD_DATA  EQU  PORTB
00031 LCD_DATA_TRIS EQU  TRI$B

```

```

00032 ; 
00033 ; else
00034 ;
00035 LCD_DATA EQU PORTD
00036 LCD_DATA_TRIS EQU TRISD
00037 ;
00038 endif
00039 ;
00040 LCD_CNTL EQU PORTA
00041 ;
00042 ;
00043 ;
00044 ; LCD Display Commands and Control Signal names.
00045 ;
00046 if ( Four_bit && !Data_HI )
00047 ;
00048 E EQU 0 ; LCD Enable control line
00049 RW EQU 1 ; LCD Read/Write control line
00050 RS EQU 2 ; LCD Register Select control line
00051 ;
00052 else
00053 ;
00054 E EQU 3 ; LCD Enable control line
00055 RW EQU 2 ; LCD Read/Write control line
00056 RS EQU 1 ; LCD Register Select control line
00057 ;
00058 endif
00059 ;
00060 ;
00061 TEMP1 EQU 0x030 ; RESET_VECTOR_START ; RESET vector location
00062 ;
00063 org RESET_V GOTO START ;
00064 RESET
00065 ;
00066 ; This is the Peripheral Interrupt routine. Should NOT get here
00067 ;
00068 page org ISR_V ; Interrupt vector location
00069 org ISR_V
00070 PER_INT_V
00071 ERROR1_ BCF STATUS, RP0 ; Bank 0
00072 BSF PORTC, 0
00073 BCF PORTC, 0
00074 GOTO ERROR1
00075 ;
00076 ;
00077 ;
00078 START
00079 ; POWER_ON Reset (Beginning of program)

```

```

0008 0183           CLRF    STATUS      ; Do initialization (Bank 0)
0009 018B           CLRF    INTCON
000A 018C           CLRF    PIR1      ; Bank 1
000B 1683           BSF     STATUS, RP0   ; The LCD module does not like to work w/ weak pull-ups
000C 3000           MOVWF   0x00      ; 
000D 0081           OPTION_REG
000E 018C           CLRF    PIE1      ; Disable all peripheral interrupts
000F 1283           ; *****
0010 0185           ; *****
0011 0186           ; *****
0012 0187           ; *****
0013 0188           ; *****
0014 0189           ; *****
0015 1010           ; *****
0016 1683           ; *****
0017 0185           ; *****
0018 30F0           ; *****
0019 0086           ; *****
001A 0187           ; *****
001B 1407           ; *****
001C 0188           ; *****
001D 0189           ; *****
001E 140C           ; *****
001F 1781           ; *****
0020 1283           ; *****
00079             CLRF    STATUS      ; Do initialization (Bank 0)
00080             CLRF    INTCON
00081             CLRF    PIR1      ; Bank 1
00082             BSF     STATUS, RP0   ; The LCD module does not like to work w/ weak pull-ups
00083             MOVWF   0x00      ; 
00084             OPTION_REG
00085             CLRF    PIE1      ; Disable all peripheral interrupts
00086             ; *****
00087             ; *****
00088             ; *****
00089             MOVWF   0xFF      ; Port A is Digital.
00090             ; *****
00091             ; *****
00092             ; *****
00093             BCF    STATUS, RP0      ; Bank 0
00094             CLRF    PORTA     ; ALL PORT output should output Low.
00095             CLRF    PORTB
00096             CLRF    PORTC
00097             CLRF    PORTD
00098             CLRF    PORTE
00099             BCF    T1CON, TMR1ON    ; Timer 1 is NOT incrementing
00100            ; *****
00101            BSF    STATUS, RP0      ; Select Bank 1
00102            CLRF    TRISA     ; RA5 - 0 outputs
00103            MOVWF  0xF0      ; RB7 - 4 inputs, RB3 - 0 outputs
00104            TRISB
00105            CLRF    TRISC     ; RC Port are outputs
00106            BSF    TRISC, T1OSO    ; RC0 needs to be input for the oscillator to function
00107            CLRF    TRISD     ; RD Port are outputs
00108            CLRF    TRISE     ; RE Port are outputs
00109            BSF    PIE1, TMR1IE    ; Enable TMR1 Interrupt
00110            BSF    OPTION_REG, NOT_RBPU ; Disable PORTB pull-ups
00111            BCF    STATUS, RP0      ; Select Bank 0
00112            ; *****
00113            page
00114            ; *****
00115            ; Initialize the LCD Display Module
00116            ; *****
00117            CLRF    LCD_CNTL    ; ALL PORT output should output Low.
00118            ; *****
00119            DISPLAY_INIT
00120            if ( Four_bit && !Data_HI )
00121            MOVLW  0x02      ; Command for 4-bit interface low nibble
00122            endif
00123            ; *****
00124            if ( Four_bit && Data_HI )
00125            MOVLW  0x020     ; Command for 4-bit interface high nibble

```

```

00126      endif
00127      ;
00128      if ( !Four_bit )
00129          MOVLW 0x038          ; Command for 8-bit interface
00130      endif
00131      ;
00132      MOVWF LCD_DATA      ;
00133          BSF   LCD_CNTL, E    ;
00134          BCF   LCD_CNTL, E    ;
00135      ;
00136      ; This routine takes the calculated times that the delay loop needs to
00137      ; be executed, based on the LCD_INIT_DELAY EQUate that includes the
00138      ; frequency of operation. These use registers before they are needed to
00139      ; store the time.
00140      ;
00141      LCD_DELAY     MOVLW LCD_INIT_DELAY      ; Use MSD and LSD Registers to Initialize LCD
00142          MOVLW MSD           ; MSD
00143          CLRF  LSD           ; LSD
00144      LOOP2        DECFSZ LSD, F            ; Delay time = MSD * ((3 * 256) + 3) * Tcy
00145          GOTO  LOOP2           ; 
00146          DECFSZ MSD, F            ; 
00147      END_LCD_DELAY    GOTO  LOOP2           ; 
00148          ;
00149      ; Command sequence for 2 lines of 5x7 characters
00150      ;
00151      ;
00152      CMD_SEQ
00153      ;
00154      if ( Four_bit )
00155          if ( !Data_HI )
00156              MOVLW 0X02          ; 4-bit low nibble xfer
00157          else
00158              MOVLW 0X020         ; 4-bit high nibble xfer
00159          endif
00160      ;
00161      else
00162          MOVLW 0X038          ; 8-bit mode
00163      endif
00164      ;
00165      MOVWF LCD_DATA      ; This code for both 4-bit and 8-bit modes
00166          BSF   LCD_CNTL, E    ;
00167          BCF   LCD_CNTL, E    ;
00168      ;
00169      if ( Four_bit )
00170          if ( !Data_HI )
00171              MOVLW 0x08          ; 4-bit low nibble xfer
00172          else

```

```

00173      MOVLW    0x080          ; 4-bit high nibble xfer
00174      endif
00175      MOVWF    LCD_DATA       ;
00176      BSF     LCD_CNTL, E    ;
00177      BCF     LCD_CNTL, E    ;
00178      endif
00179      ; Busy Flag should be valid after this point
00180      ; Busy Flag should be valid after this point
00181      ;
00182      MOVLW    DISP_ON        ;
00183      CALL     SEND_CMD       ;
00184      MOVLW    CLR_DISP       ;
00185      CALL     SEND_CMD       ;
00186      MOVLW    ENTRY_INC      ;
00187      CALL     SEND_CMD       ;
00188      MOVLW    DD_RAM_ADDR    ;
00189      CALL     SEND_CMD       ;
00190      ;
00191      page
00192      ;
00193      ; Send a message the hard way
00194      MOVLW    'M',           ;
00195      CALL     SEND_CHAR     ;
00196      MOVLW    'i',           ;
00197      CALL     SEND_CHAR     ;
00198      MOVLW    'c',           ;
00199      CALL     SEND_CHAR     ;
00200      MOVLW    'r',           ;
00201      CALL     SEND_CHAR     ;
00202      MOVLW    'o',           ;
00203      CALL     SEND_CHAR     ;
00204      MOVLW    'c',           ;
00205      CALL     SEND_CHAR     ;
00206      MOVLW    'h',           ;
00207      CALL     SEND_CHAR     ;
00208      MOVLW    'i',           ;
00209      CALL     SEND_CHAR     ;
00210      MOVLW    'p',           ;
00211      CALL     SEND_CHAR     ;
00212      MOVLW    B'11000000',   ; Address DDRam first character, second line
00213      CALL     SEND_CMD       ;
00214      MOVLW    0              ;
00215      MOVLW    0              ;
00216      MOVLW    0              ;
00217      MOVLW    0              ;
00218      dispmsg
00219      TEMP1
004B      30C0          ; Demonstration of the use of a table to output a message
004C      2068          ; Table address of start of message
004D      3000          ; TEMP1 holds start of message address
004E      00B0

```

```

004F 2083
0050 39FF
0051 1903
0052 2857
0053 205F
0054 0830
0055 3E01
0056 284E
0057 2857
00220 call Table
00221 andlw 0FFh ;Check if at end of message (zero
00222 btfsc STATUS, Z ;returned at end)
00223 goto out
00224 call SEND_CHAR
00225 movf TEMP1,w ;Display character
00226 addlw 1 ;Point to next character
00227 goto dispmsg
00228 out
00229 loop
00230 goto loop ;Stay here forever
00231 ;
00232 ;
00233 INIT_DISPLAY
00234 MOVLW DISP_ON ; Display On, Cursor On
00235 CALL SEND_CMD ; Send This command to the Display Module
00236 MOVLW CLR_DISP ; Clear the Display
00237 CALL SEND_CMD ; Send This command to the Display Module
00238 MOVLW ENTRY_INC ; Set Entry Mode Inc., No shift
00239 CALL SEND_CMD ; Send This command to the Display Module
00240 RETURN
00241 ;
00242 page
00243 ;
00244 ;***** The LCD Module Subroutines *****
00245 ; * SendChar - Sends character to LCD
00246 ; *This routine splits the character into the upper and lower
00247 ; * nibbles and sends them to the LCD, upper nibble first.
00248 if ( Four_bit ) ; 4-bit Data transfers?
00249 ; iff ( Data_HI ) ; 4-bit transfers on the high nibble of the PORT
00250 ;
00251 ;
00252 ;*****SendChar - Sends character to LCD *****
00253 ; *SendChar - Sends character to LCD
00254 ; *This routine splits the character into the upper and lower
00255 ; *nibbles and sends them to the LCD, upper nibble first.
00256 ; *****
00257 ;
00258 SEND_CHAR
00259 MOVWF CHAR ;Character to be sent is in W
00260 CALL BUSY_CHECK ;Wait for LCD to be ready
00261 MOVF CHAR, W
00262 ANDLW 0xFF ;Get upper nibble
00263 MOVWF LCD_DATA ;Send data to LCD
00264 BCF LCD_CNTL, RW ;Set LCD to read
00265 BSF LCD_CNTL, RS ;Set LCD to data mode
00266 BSF LCD_CNTL, E ;toggle E for LCD

```

```

00267      BCF      LCD_CNTL, E
00268      SWAPF   CHAR, W
00269      ANDLW   0xFF          ; Get lower nibble
00270      MOVWF   LCD_DATA       ; Send data to LCD
00271      BSF      LCD_CNTL, E ; toggle E for LCD
00272      BCF      LCD_CNTL, E
00273      RETURN
00274      ;
00275      else
00276      ;
00277      ; *****
00278      ; * SEND_CHAR - Sends character to LCD
00279      ; * This routine splits the character into the upper and lower
00280      ; * nibbles and sends them to the LCD, upper nibble first.
00281      ; * The data is transmitted on the PORT<3:0> pins
00282      ; *****
00283      ;
00284      SEND_CHAR
00285      MOVWF   CHAR           ; Character to be sent is in W
00286      CALL    BUSY_CHECK     ; Wait for LCD to be ready
00287      SWAPF   CHAR, W
00288      ANDLW   0x0F          ; Get upper nibble
00289      MOVWF   LCD_DATA       ; Send data to LCD
00290      BCF      LCD_CNTL, RW ; Set LCD to read
00291      BSF      LCD_CNTL, RS ; Set LCD to data mode
00292      BSF      LCD_CNTL, E ; toggle E for LCD
00293      BCF      LCD_CNTL, E
00294      MOVF    CHAR, W
00295      ANDLW   0x0F          ; Get lower nibble
00296      MOVWF   LCD_DATA       ; Send data to LCD
00297      BSF      LCD_CNTL, E ; toggle E for LCD
00298      BCF      LCD_CNTL, E
00299      RETURN
00300      ;
00301      endif
00302      else
00303      ;
00304      ; *****
00305      ; * SEND_CHAR - Sends character contained in register W to LCD
00306      ; * This routine sends the entire character to the PORT<7:0> pins
00307      ; * The data is transmitted on the PORT<7:0> pins
00308      ; *****
00309      ;
00310      SEND_CHAR
00311      MOVWF   CHAR           ; Character to be sent is in W
00312      CALL    BUSY_CHECK     ; Wait for LCD to be ready
00313      MOVF    CHAR, W
005F      00B6
0060      2071
0061      0836

```

```

0062 0088
0063 1105
0064 1485
0065 1585
0066 1185
0067 0008

00314      MOVWF    LCD_DATA           ; Send data to LCD
00315      BCF     LCD_CNTL, RW        ; Set LCD in read mode
00316      BSF     LCD_CNTL, RS        ; Set LCD in data mode
00317      BSF     LCD_CNTL, E         ; toggle E for LCD
00318      BCF     LCD_CNTL, E         ; toggle E for LCD
00319      RETURN
00320      ;
00321      endif
00322      ;
00323      page
00324      ;
00325      ;*****Cmd - Sends command to LCD
00326      ;*****Sends command to LCD
00327      ;* This routine splits the command into the upper and lower
00328      ;* nibbles and sends them to the LCD, upper nibble first.
00329      ;* The data is transmitted on the PORT<3:0> pins
00330      ;*****Sends command to LCD
00331      ;
00332      if ( Four_bit )          ; 4-bit Data transfers?
00333      ;
00334      if ( Data_HI )          ; 4-bit transfers on the high nibble of the PORT
00335      ;
00336      ;*****SEND_CMD - Sends command to LCD
00337      ;* SEND_CMD - Sends command to LCD
00338      ;* This routine splits the command into the upper and lower
00339      ;* nibbles and sends them to the LCD, upper nibble first.
00340      ;*****SEND_CMD
00341      ;
00342      SEND_CMD
00343      MOVWF    CHAR             ; Character to be sent is in W
00344      CALL    BUSY_CHECK         ; Wait for LCD to be ready
00345      MOVF    CHAR,W
00346      ANDLW   0xFF00           ; Get upper nibble
00347      MOVWF    LCD_DATA          ; Send data to LCD
00348      BCF     LCD_CNTL, RW        ; Set LCD to read
00349      BCF     LCD_CNTL, RS        ; Set LCD to command mode
00350      BSF     LCD_CNTL, E         ; toggle E for LCD
00351      BCF     LCD_CNTL, E         ; toggle E for LCD
00352      SWAPP   CHAR,W
00353      ANDLW   0xFF00           ; Get lower nibble
00354      MOVWF    LCD_DATA          ; Send data to LCD
00355      BSF     LCD_CNTL, E         ; toggle E for LCD
00356      BCF     LCD_CNTL, E         ; toggle E for LCD
00357      RETURN
00358      ;
00359      else
00360      ;

```

```

00361 SEND_CMD
00362     MOVWF    CHAR           ; Character to be sent is in W
00363     CALL    BUSY_CHECK      ; Wait for LCD to be ready
00364     SWAPF   CHAR, W
00365     ANDlw   0x0F           ; Get upper nibble
00366     MOVWF    LCD_DATA       ; Send data to LCD
00367     BCF    LCD_CNTL, RW    ; Set LCD to read
00368     BCF    LCD_CNTL, RS    ; Set LCD to command mode
00369     BSF    LCD_CNTL, E     ; toggle E for LCD
00370     BCF    LCD_CNTL, E
00371     MOVF    CHAR, W
00372     ANDlw   0x0F           ; Get lower nibble
00373     MOVWF    LCD_DATA       ; Send data to LCD
00374     BSF    LCD_CNTL, E     ; toggle E for LCD
00375     BCF    LCD_CNTL, E
00376     RETURN
00377 ;
00378     endif
00379     else
00380 ;
00381 ;*****
00382 ; * SEND_CMD - Sends command contained in register W to LCD
00383 ; * This routine sends the entire character to the PORT
00384 ; * The data is transmitted on the PORT<7:0> pins
00385 ;*****
00386     0068 SEND_CMD
00387     MOVWF    CHAR           ; Command to be sent is in W
00388     CALL    BUSY_CHECK      ; Wait for LCD to be ready
00389     MOVF    CHAR, W
00390     MOVWF    LCD_DATA       ; Send data to LCD
00391     BCF    LCD_CNTL, RW    ; Set LCD in read mode
00392     BCF    LCD_CNTL, RS    ; Set LCD in command mode
00393     BSF    LCD_CNTL, E     ; toggle E for LCD
00394     BCF    LCD_CNTL, E
00395     BCF    LCD_CNTL, E
00396     RETURN
00397 ;
00398     endif
00399 ;
00400     page
00401 ;
00402     if ( Four_bit )          ; 4-bit Data transfers?
00403 ;
00404     if ( Data_HI )           ; 4-bit transfers on the high nibble of the PORT
00405 ;
00406 ;*****
00407 ; * This routine checks the busy flag, returns when not busy

```

```

00408 ; * Affects:
00409 ; * TEMP - Returned with busy/address *
00410 ; *****
00411 ;
00412 BUSY_CHECK
00413 BSF STATUS, RP0 ; Select Register Bank1
00414 MOVLW 0xFF ; Set Port_D for input
00415 MOVWF LCD_DATA_TRIS
00416 BCF STATUS, RP0 ; Select Register Bank0
00417 BCF LCD_CNTL, RS ; Set LCD for Command mode
00418 BCF LCD_CNTL, RW ; Setup to read busy flag
00419 BCF LCD_CNTL, E ; Set E high
00420 BCF LCD_CNTL, E ; Set E low
00421 MOVF LCD_DATA, W ; Read upper nibble busy flag, DDRam address
00422 ANDLW 0xFF ; Mask out lower nibble
00423 MOVWF TEMP ; Toggle E to get lower nibble
00424 BCF LCD_CNTL, E ; Read lower nibble busy flag, DDRam address
00425 BCF LCD_DATA, W ; Mask out upper nibble
00426 SWAPP 0x0F ; Combine nibbles
00427 ANDLW 0x0F ; Check busy flag, high = busy
00428 IORWF TEMP, F ; If busy, check again
00429 BTFSR TEMP, 7
00430 GOTO BUSY_CHECK
00431 BCF LCD_CNTL, RW
00432 BCF STATUS, RP0 ; Select Register Bank1
00433 MOVLW 0x0F ; Set Port_D for output
00434 MOVWF LCD_DATA_TRIS
00435 BCF STATUS, RP0 ; Select Register Bank0
00436 RETURN
00437 ;
00438 else ; 4-bit transfers on the low nibble of the PORT
00439 ;
00440 *****
00441 ; * This routine checks the busy flag, returns when not busy *
00442 ; * Affects:
00443 ; * TEMP - Returned with busy/address *
00444 ; *****
00445 ;
00446 BUSY_CHECK
00447 BSF STATUS, RP0 ; Bank 1
00448 MOVLW 0xFF ; Set PortB for input
00449 MOVWF LCD_DATA_TRIS
00450 BCF STATUS, RP0 ; Bank 0
00451 BCF LCD_CNTL, RS ; Set LCD for Command mode
00452 BCF LCD_CNTL, RW ; Setup to read busy flag
00453 BCF LCD_CNTL, E ; Set E high
00454 BCF LCD_CNTL, E ; Set E low

```

```

00455 SWAPF LCD_DATA, W ; Read upper nibble busy flag, DDram address
00456 ANDLW 0xFF0 ; Mask out lower nibble
00457 MOVWF TEMP ; Toggle E to get lower nibble
00458 BSF LCD_CNTL, E ; Toggle E to get lower nibble
00459 BCF LCD_CNTL, E ; Read lower nibble busy flag, DDram address
00460 MOVF LCD_DATA, W ; Mask out upper nibble
00461 ANDLW 0x0F ; Combine nibbles
00462 IORWF TEMP, F ; Check busy flag, high = busy
00463 BTFSR TEMP, 7 ; If busy, check again
00464 GOTO BUSY_CHECK
00465 BCF LCD_CNTL, RW ; Bank 1
00466 BSF STATUS, RP0 ; Bank 1
00467 MOVLW 0xFF0 ; RB7 - 4 = inputs, RB3 - 0 = output
00468 MOVWF LCD_DATA_TRIS ; Bank 0
00469 BCF STATUS, RP0 ; Bank 0
RETURN

00470 ;*
00471 ;*
00472 endif
00473 else
00474 ;*****
00475 ;***** This routine checks the busy flag, returns when not busy *****
00476 ;* Affects:
00477 ;*
00478 ;* TEMP - Returned with busy/address
00479 ;***** Returned with busy/address *****
00480 ;*
00481 BUSY_CHECK
00482 BCF STATUS,RP0 ; Select Register Bank1
00483 MOVLW 0xFF ; Set port_D for input
00484 MOVWF LCD_DATA_TRIS ; Select Register Bank0
00485 BCF LCD_CNTL, RS ; Set LCD for command mode
00486 BCF LCD_CNTL, RW ; Setup to read busy flag
00487 BSF LCD_CNTL, E ; Set E high
00488 BSF LCD_CNTL, E ; Set E low
00489 BCF LCD_CNTL, E ; Read busy flag, DDram address
00490 MOVF LCD_DATA, W ; TEMP
00491 MOVWF TEMP ; Check busy flag, high=busy
00492 BTFSR TEMP, 7 ; Bank 1
00493 GOTO BUSY_CHECK
00494 BCF LCD_CNTL, RW ; Select Register Bank1
00495 BSF STATUS, RP0 ; Set port_D for input
00496 MOVLW 0x000 ; Select Register Bank0
00497 MOVWF LCD_DATA_TRIS ; Set port_D for output
00498 BCF STATUS, RP0 ; Select Register Bank0
RETURN

0071 1683
0072 30FF
0073 0088
0074 1283
0075 1085
0076 1505
0077 1585
0078 1185
0079 0808
007A 00B5
007B 1BB5
007C 2871
007D 1105
007E 1683
007F 3000
0080 0088
0081 1283
0082 0008
00499 ;*
00500 ;*
00501 ;*
endif

```

```

0083    0782      page
0083    00502     ;          page
0083    00503     ;          page
0083    00504     Table
0084    344D      00505     addwf   F
0084    00506     retlw   `M'
0085    3469      00507     addwf   F
0085    00508     retlw   `i'
0086    3463      00508     addwf   F
0086    00509     retlw   `c'
0087    3472      00509     addwf   F
0087    00510     retlw   `r'
0088    346F      00510     addwf   F
0088    00511     retlw   `o'
0089    3463      00511     addwf   F
0089    00512     retlw   `c'
008A    3468      00512     addwf   F
008A    00513     retlw   `h'
008B    3469      00513     addwf   F
008B    00514     retlw   `i'
008C    3470      00514     addwf   F
008C    00515     retlw   `p'
008D    3420      00515     addwf   F
008D    00516     retlw   ` '
008E    3454      00516     addwf   F
008E    00517     retlw   `T'
008F    3465      00517     addwf   F
008F    00518     retlw   `e'
0090    3463      00518     addwf   F
0090    00519     retlw   `c'
0091    3468      00519     addwf   F
0091    00520     retlw   `h'
0092    346E      00520     addwf   F
0092    00521     retlw   `n'
0093    346F      00521     addwf   F
0093    00522     retlw   `o'
0094    346C      00522     addwf   F
0094    00523     retlw   `l'
0095    346F      00523     addwf   F
0095    00524     retlw   `o'
0096    3467      00524     addwf   F
0096    00525     retlw   `g'
0097    3479      00525     addwf   F
0097    00526     retlw   `y'
0098    3400      00526     Table_End
0098    00527     addwf   F
0098    00527     retlw   0
0098    00528     if ( (Table & 0x0FF) >= (Table_End & 0x0FF) )
0098    00529     MESSG  "Warning - User Defined: Table Table crosses page boundary in computed jump"
0098    00530     endif
0098    00531     00532     ;
0098    00532     00533     ;
0098    00534     00535     end
0098    00536

```

MEMORY USAGE MAP ('X' = Used, ' - ' = Unused)

```
0000 : X--XXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX  
0040 : XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX  
0080 : XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX  
-----  
-----
```

All other memory blocks unused.

```
Program Memory Words Used: 150  
Program Memory Words Free: 1898
```

```
Errors : 0  
Warnings : 0 reported, 0 suppressed  
Messages : 0 reported, 12 suppressed
```



MICROCHIP

WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office

2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support: 480-792-7627
Web Address: <http://www.microchip.com>

Atlanta

3780 Mansell Road, Suite 130
Alpharetta, GA 30022
Tel: 770-640-0034
Fax: 770-640-0307

Boston

2 Lan Drive, Suite 120
Westford, MA 01886
Tel: 978-692-3848
Fax: 978-692-3821

Chicago

333 Pierce Road, Suite 180
Itasca, IL 60143
Tel: 630-285-0071
Fax: 630-285-0075

Dallas

4570 Westgrove Drive, Suite 160
Addison, TX 75001
Tel: 972-818-7423
Fax: 972-818-2924

Detroit

Tri-Atria Office Building
32255 Northwestern Highway, Suite 190
Farmington Hills, MI 48334
Tel: 248-538-2250
Fax: 248-538-2260

Kokomo

2767 S. Albright Road
Kokomo, IN 46902
Tel: 765-864-8360
Fax: 765-864-8387

Los Angeles

18201 Von Karman, Suite 1090
Irvine, CA 92612
Tel: 949-263-1888
Fax: 949-263-1338

Phoenix

2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7966
Fax: 480-792-4338

San Jose

1300 Terra Bella Avenue
Mountain View, CA 94043
Tel: 650-215-1444

Toronto

6285 Northam Drive, Suite 108
Mississauga, Ontario L4V 1X5, Canada
Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Australia

Suite 22, 41 Rawson Street
Epping 2121, NSW
Australia
Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing

Unit 706B
Wan Tai Bei Hai Bldg.
No. 6 Chaoyangmen Bei Str.
Beijing, 100027, China
Tel: 86-10-85282100
Fax: 86-10-85282104

China - Chengdu

Rm. 2401-2402, 24th Floor,
Ming Xing Financial Tower
No. 88 TiDU Street
Chengdu 610016, China

China - Fuzhou

Unit 28F, World Trade Plaza
No. 71 Wusi Road
Fuzhou 350001, China
Tel: 86-591-7503506
Fax: 86-591-7503521

China - Hong Kong SAR

Unit 901-6, Tower 2, Metroplaza
223 Hing Fong Road
Kwai Fong, N.T., Hong Kong
Tel: 852-2401-1200
Fax: 852-2401-3431

China - Shanghai

Room 701, Bldg. B
Far East International Plaza
No. 317 Xian Xia Road
Shanghai, 200051
Tel: 86-21-6275-5700
Fax: 86-21-6275-5060

China - Shenzhen

Rm. 1812, 18/F, Building A, United Plaza
No. 5022 Binhe Road, Futian District
Shenzhen 518033, China
Tel: 86-755-82901380
Fax: 86-755-8295-1393

China - Shunde

Room 401, Hongjian Building
No. 2 Fengxiangnan Road, Ronggui Town
Shunde City, Guangdong 528303, China
Tel: 86-765-8395507 Fax: 86-765-8395571

China - Qingdao

Rm. B505A, Fullhope Plaza,
No. 12 Hong Kong Central Rd.
Qingdao 266071, China
Tel: 86-532-5027355 Fax: 86-532-5027205

India

Divyasree Chambers
1 Floor, Wing A (A3/A4)
No. 11, O'Shaugnessey Road
Bangalore, 560 025, India
Tel: 91-80-2290061 Fax: 91-80-2290062

Japan

Benex S-1 6F
3-18-20, Shinyokohama
Kohoku-Ku, Yokohama-shi
Kanagawa, 222-0033, Japan
Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea

168-1, Youngbo Bldg. 3 Floor
Samsung-Dong, Kangnam-Ku
Seoul, Korea 135-882
Tel: 82-2-554-7200 Fax: 82-2-558-5932 or
82-2-558-5934

Singapore

200 Middle Road
#07-02 Prime Centre
Singapore, 188980
Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan

Kaohsiung Branch
30F - 1 No. 8
Min Chuan 2nd Road
Kaohsiung 806, Taiwan
Tel: 886-7-536-4818
Fax: 886-7-536-4803

Taiwan

Taiwan Branch
11F-3, No. 207
Tung Hua North Road
Taipei, 105, Taiwan
Tel: 886-2-2717-7175 Fax: 886-2-2545-0139

EUROPE

Austria

Durisolstrasse 2
A-4600 Wels
Austria
Tel: 43-7242-2244-399
Fax: 43-7242-2244-393

Denmark

Regus Business Centre
Lautrup hoj 1-3
Ballerup DK-2750 Denmark
Tel: 45-4420-9895 Fax: 45-4420-9910

France

Parc d'Activite du Moulin de Massy
43 Rue du Saule Trapu
Batiment A - 1er Eteage
91300 Massy, France
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany

Steinheilstrasse 10
D-85737 Ismaning, Germany
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Italy

Via Quasimodo, 12
20025 Legnano (MI)
Milan, Italy
Tel: 39-0331-742611
Fax: 39-0331-466781

Netherlands

P. A. De Biesbosch 14
NL-5152 SC Drunen, Netherlands
Tel: 31-416-690399
Fax: 31-416-690340

United Kingdom

505 Eskdale Road
Winnersh Triangle
Wokingham
Berkshire, England RG41 5TU
Tel: 44-118-921-5869
Fax: 44-118-921-5820

11/24/03